

INSTRUCTIONS

- 1) Drill  $3/16$  holes as shown by arrows
- 2) Drop SS screws into holes

